ATS150 Series Stage User's Manual

P/N: EDA125 (Revision 1.01.00)



Dedicated to the Science of Motion Aerotech, Inc. 101 Zeta Drive, Pittsburgh, PA, 15238 Phone: 412-963-7470

Fax: 412-963-7459 www.aerotech.com



Product Registration

Register online at: http://www.-aerotech.com/prodreg.cfm

Technical Support

United States Headquarters:

Phone: (412) 967-6440 Fax: (412) 967-6870

Email: service@aerotech.com

United Kingdom:

Phone: +44 118 940 9400 Fax: +44 118 940 9401

Email: service@aerotech.co.uk

Germany:

Phone: +49 911 967 9370 Fax: +49 911 967 93720

Email: service@aerotechgmbh.de

Japan:

Phone: +81(0)47-489-1741 (Sales) Phone: +81(0)47-489-1742 (Service)

Fax: +81(0)47-489-1743

Email: service@aerotechkk.com.jp

China:

Phone: +852-3793-3488

Email: saleschina@aerotech.com

Revision History

Revision 1.01.00 March 21, 2011 Revision 1.00.00 March 10, 2006

Table of Contents Table of Contents.....iii List of Figures. v List of Tables. vii Chapter 1: Overview 1 1.1. Standard Features 2 1.3. Safety Procedures and Warnings. 6 1.4. EC Declaration of Incorporation 8 Chapter 2: Installation 9 2.1. Unpacking and Handling the Stage. 9 2.5. Electrical Installation 12 2.5.1. DC Servo Motor Wiring 12 Chapter 3: Operating Specifications 13 3.1. Environmental Specifications. 13 3.3. Basic Specifications 15 3.5. Optical Limit Switch Assembly. 20 3.5.1. Limit Switch Operation. 20 3.5.2. Limit Interface 21 3.6. Vacuum Operation 22 Chapter 4: Maintenance 23 4.2. Lubrication and Cleaning Process. 24 4.3. Important Notes on Lubrication 25 4.4. Recommended Lubricants and Cleaning Solvents. 25 Appendix B: Technical Changes 2931 Index Reader's Comments. 32

List of Figures

Figure 1-1:	Typical ATS150 Series Linear Positioning Stage	1
Figure 1-2:	ATS150 with Cutaway View of Ballscrew.	2
Figure 1-3:	Components of a Typical Motor, Encoder, and ATS150 Series Stage	3
Figure 2-1:	Results of Coplanar Versus Non-Coplanar Mounting.	10
Figure 3-1:	Load Capability and Travel Life of the ATS150 Stages	17
Figure 3-2:	Torque Required to Turn ATS150 Series Ball-screw with Various Loads and Leads	19
Figure 3-3:	ATS150 Internal View Showing Optical Limit Switch Assembly	20
Figure 3-4:	ATS150 Series Limit Switch Wiring.	21

www.aerotech.com

List of Tables

Table 1-1:	Model Numbering System	4
	Environmental Specifications	
Table 3-2:	ATS150 Series Positioning Stage Specifications.	15
Table 3-3:	Motor Specifications.	16
Table 3-4:	Applied Load Coeffcients	18
Table 3-5:	Limit Interface Pin Assignments	21
Table B-1:	Current Changes (1.01.00)	29
Table B-2:	Archived Changes.	30

www.aerotech.com

Chapter 1: Overview

This manual describes Aerotech's ATS150 series of linear motor positioning stages. Figure 1-1 shows a typical ATS150 positioning stage.

The ATS150 series are low profile linear positioning stages. These stages provide highly accurate positioning with travel ranges from 100 mm to 250 mm (4-10 in). They have a low profile, compact design, yet they are designed for high stiffness and stability. The ATS150 series uses a long life, linear motion guide (LMG) bearing system that provides ultra fine positioning resolution (up to 0.1 micron) with an average accuracy better than \pm 0.7 micron/25 mm (\pm 0.00003 in/in).

This chapter introduces standard and optional features of the ATS150 stages, explains the model numbering system, and gives general safety precautions.



Figure 1-1: Typical ATS150 Series Linear Positioning Stage

NOTE: Aerotech continually improves its product offerings, and listed options may be superseded at any time. Refer to the most recent edition of the Aerotech Motion Control Product Guide for the most current product information at www.aerotech.com.

1.1. Standard Features

ATS150 series stages use a precision ground ball-screw (see cutaway view in Figure 1-2) that is preloaded to eliminate backlash. High-quality duplex bearings are used to eliminate axial play, while the LMG bearing system provides high load capability, stiffness, and continuous carriage support over the entire travel distance. Internal contamination is prevented with integral bellows way-covers. The connecting nut on the ball-screw has wipers that prevent internal contamination of the drive and bearing system, thereby ensuring high accuracy over the expected travel life in excess of 100,000,000 inches.




Figure 1-2: ATS150 with Cutaway View of Ballscrew

Additional features of the ATS150 series stages include:

- Optical limit switches and cushioned end stops
- Aluminum alloy (standard) or steel construction (for severe temperature environments)
- English or Metric mounting holes on the stage table (1/4-20 on a 1" square grid pattern or M6 on a 25 mm grid pattern)
- Micro-stepping, DC servo motors or brushless servo motors
- Vacuum preparation for operation to 10⁻⁶ torr.
- High accuracy (HAL) stage option providing positioning accuracy of ±1 micron over full travel and a ±.25 micron bi-directional repeatability
- Precision multi-axis configurations (such as XY and XYZ) having orthogonality within 5 arc seconds.

Motors are mounted to a plate on one end of ATS150 series stages. A motor housing and encoder are optional on most models. A cable or set of cables carries motor power, encoder feedback as well as limit switch signals to the appropriate hardware devices (such as axis controllers and amplifiers).

2




Figure 1-3: Components of a Typical Motor, Encoder, and ATS150 Series Stage

NOTE: Motor and limit wiring can be integral (extending directly from the electrical housing) as shown in Figure 1-3, or it can attach to a connector located on the motor itself (depending on the model of motor housing ordered).

1.2. Model Numbers

The table below lists the available options. Aerotech continually improves its product offerings, and listed options may be superseded at any time. Refer to the most recent edition of the Aerotech Motion Control Product Guide for the most current product information at www.aerotech.com.

Table 1-1: Model Numbering System

Travel Distance					
ATS150-100	100 mm (4 in) travel stage with limits				
ATS150-150	150 mm (6 in) travel stage with limits				
ATS150-200	200 mm (8 in) travel stage with limits				
ATS150-250	250 mm (10 in) travel stage with limits				
Stage Construction Op	tions				
/VAC3	Vacuum preparation of stage to 10 ⁻³ torr				
/VAC6	Vacuum preparation of stage to 10 ⁻⁶ torr				
/STEEL	All steel construction				
High-Accuracy Linear I	Encoders				
-LN10AS	High-accuracy linear encoder for ATS150-100; amplified sine output 1 Vpp (4 μm signal period); requires signal multiplier				
-LN15AS	High-accuracy linear encoder for ATS150-150; amplified sine output 1 Vpp (4 μm signal period); requires signal multiplier				
Note: Internal signal mul	Itipliers available with A3200 amplifier products.				
Mounting and Grid Patte	ern				
-M	Metric dimension mounting pattern and holes				
-U	English dimension mounting pattern and holes				
Drive Screw					
-20P	2 mm/rev precision-ground ball screw				
-40P	4 mm/rev precision-ground ball screw				
Motor					
-BMS	Brushless servomotor with connectors and 1000-line encoder; requires cable (BMS60-A-D25-E1000H/)				
-SM	Stepping motor with connector and home marker pulse (one per rev); requires cable (101SMB2-HM/)				
-NM	No motor or encoder				
Limits					
-NC	Normally-closed end of travel limit switches (standard)				
-NO	Normally-open end of travel limit switches				
-9DU	With 9-pin limit connector				
-FLY	With flying leads				
Options					
-BRK23	24 VDC spring-set motor brake for NEMA 23 motor				
-FB150	Fold-back motor configuration				
-FB-BRK1	Fold-back motor configuration with 24 VDC spring-set motor brake for NEMA 23 motor				

Table 1-1: Model Numbering System (continued)

Coupling	
-NO COUPLING	No coupling
-STD COUPLING	0.25 in coupling
-LGR MTR COU- PLING	0.375 in coupling
Accessories (to be or	dered as separate line item)
ALIGNMENT-NPA	Non-precision XY assembly
ALIGNMENT-NPAZ	Non-precision XZ or YZ assembly
ALIGNMENT-PA10	XY assembly; 10 arc sec orthogonal
ALIGNMENT-PA10Z	XZ or YZ assembly with L-bracket; 10 arc second orthogonal
ALIGNMENT-PA5	XY assembly; 5 arc sec orthogonal
ALIGNMENT-PA5Z	XZ or YZ assembly with L-bracket; 5 arc second orthogonal
HALAR	High-accuracy system – linear error correction for accuracy and repeatability
HALSF	High-accuracy system – improved straightness and flatness
HDZ2	English right-angle L-bracket; for ATS150-100 and ATS150-150 stages only
HDZ2M	Metric right-angle L-bracket; for ATS150-100 and ATS150-150 stages only
HDZ2/VAC6	VAC6 prepared English right-angle L-bracket; for ATS150-100 and ATS150-150 stages only
HDZ2M/VAC6	VAC6 prepared metric right-angle L-bracket; for ATS150-100 and ATS150-150 stages only

1.3. Safety Procedures and Warnings

The following statements apply throughout this manual. Failure to observe these precautions could result in serious injury to those performing the procedures and damage to the equipment.

This manual and any additional instructions included with the stage should be retained for the lifetime of the stage.



To minimize the possibility of electrical shock and bodily injury or death, disconnect all electrical power prior to making any electrical connections.



To minimize the possibility of electrical shock and bodily injury or death when any electrical circuit is in use, ensure that no person comes in contact with the circuitry when the stage is connected to a power source.



To minimize the possibility of bodily injury or death, disconnect all electrical power prior to making any mechanical adjustments.



Moving parts of the stage can cause crushing or shearing injuries. All personnel must remain clear of any moving parts.



Improper use of the stage can cause damage, shock, injury, or death. Read and understand this manual before operating the stage.



If the stage is used in a manner not specified by the manufacturer, the protection provided by the stage can be impaired.



Stage cables can pose a tripping hazard. Securely mount and position all stage cables to avoid potential hazards.



Do not expose the stage to environments or conditions outside the specified range of operating environments. Operation in conditions other than those specified can cause damage to the equipment.



The stage must be mounted securely. Improper mounting can result in injury and damage to the equipment.



Use care when moving the stage. Manually lifting or transporting stages can result in injury.



Only trained personnel should operate, inspect, and maintain the stage.



This stage is intended for light industrial manufacturing or laboratory use. Use of the stage for unintended applications can result in injury and damage to the equipment.



Before using this stage, perform an operator risk assessment to determine the needed safety requirements.

1.4. EC Declaration of Incorporation

Manufactorer: Aerotech, Inc.

101 Zeta Drive Pittsburgh, PA 15238

USA



herewith declares that the product:

Aerotech, Inc. ATS150 Stage

is intended to be incorporated into machinery to constitute machinery covered by the Directive 2006/42/EC as amended;

does therefore not in every respect comply with the provisions of this directive;

and that the following harmonized European standards have been applied:

EN ISO 12100-1,-2:2003+A1:2009

Safety of machinery - Basic concepts, general principles for design

ISO 14121-1:2007

Safety of machinery - Risk assessment - Par 1: Principles

EN 60204-1:2005

Safety of machinery - Electrical equipment of machines - Part 1: General requirements

and further more declares that

it is not allowed to put the equipment into service until the machinery into which it is to be incorporated or of which it is to be a component has been found and declared to be in conformity with the provisions of the Directive 2006/42/EC and with national implementing legislation, i.e. as a whole, including the equipment referred to in this Declaration.

lles Reherry

Authorized Representative:Manfred BesoldAddress:AEROTECH GmbHSüd-West-Park 90

D-90449 Nürnberg

Name:

Alex Weibel /

Position: Engineer Verifying Compliance

Location:Pittsburgh, PADate:March 21, 2011

Chapter 2: Installation

This chapter covers the mechanical aspects of setting up the stage, including proper stage handling techniques, how to prepare the mounting surface to accept the stage, how to secure the stage to the mounting surface and how to attach a payload. Also covered are the electrical aspects of setting of the stage, including motor wiring information, the optical limit switch assembly and limit/home wiring options.



Installation must follow the instructions in this chapter. Failure to follow these instructions could result in injury and damage to the equipment.

2.1. Unpacking and Handling the Stage

Carefully remove the stage from the protective shipping container. Set the stage on a smooth, flat, and clean surface. This is a simple, yet very important step in maintaining the integrity of the stage. Each stage has a label listing the system part number and serial number. These numbers contain information necessary for maintaining or updating system hardware and software. Locate this label and record the information for later reference. If any damage has occurred during shipping, report it immediately.



Improper stage handling could adversely affect the stage's performance. Therefore, use care when moving the stage. Manually lifting or transporting the stage can result in injury.



Lift the stage only by the base.



Do not use the ballscrew or motor as lifting points.

2.2. Preparing the Mounting Surface

In order for the ATS150 series stage to maintain accuracy, the mounting surface should be coplanar within 0.000010 in/in. For example, if the longest distance between the rectangular base hole pattern is 8 inches, then the mounting surface should be coplanar within 0.000080 inches. Adjustments to the mounting surface must be done before the stage is secured. Adjustments to the mounting surface must be done before the stage is secured. The effects of flatness on mounting are illustrated in Figure 2-1.




Figure 2-1: Results of Coplanar Versus Non-Coplanar Mounting

When an ATS150 series stage is mounted onto a non-coplanar surface the stage can be distorted as the mounting screws are tightened. This distortion can decrease the overall accuracy of the stage.

NOTE: The stage base is precision machined and verified for flatness prior to stage assembly at the factory. If machining is required to achieve the desired flatness, it should be performed on the mounting surface rather than the stage base. Shimming should be avoided if possible. If shimming is required, it should be minimized to improve the rigidity of the system.

2.3. Securing the Stage to the Mounting Surface

Manually position the stage table so that the access holes (0.5 in [75.0 mm] diameter) on the stage table are aligned with any two of the mounting holes (0.28 in [6,5 mm] diameter) on the under side of the stage. Install the appropriately sized screws though the access holes and secure the stage to the mounting surface. Repeat this process for each set of mounting holes.



The stage must be mounted securely. Improper mounting can result in injury and damage to the equipment.

NOTE: The stage table may offer a considerable amount of resistance when it is moved manually. This is especially true if the stage is fitted with a motor assembly.

NOTE: If the stage is not connected to a power source, and is not equipped with an optional brake, it should be possible to move the stage table by hand with steady even pressure. Do not attempt to manually move the stage if it is connected to a power source or includes an integrated brake.

2.4. Attaching the Payload to the Stage

To prevent damage to payloads, test the operation of the stage before the payload is attached to the stage table.

When attaching a payload to the stage table, the mounting interface should be coplanar within 0.000010 in/in for valid accuracies. This can be achieved by scraping or shimming the mounting surface of the payload. It is recommended that feet or pads be used on the payload surface to minimize the amount of surface area that needs to be coplanar.

2.5. Electrical Installation

Electrical installation requirements will vary depending on stage options. Installation instructions in this section are for stages equipped with standard Aerotech motors intended for use with an Aerotech motion control system. Contact Aerotech for further information regarding stages that are otherwise configured.

Aerotech motion control systems are adjusted at the factory for optimum performance. When the ATS150 series stage is part of a complete Aerotech motion control system, setup involves connecting a stage and motor combination to the appropriate drive chassis with the cables provided. Connect the provided cables to the motor and feedback connectors on the stage. Labels on the drive indicate the appropriate connections. Refer to your drive manuals and documentation for additional installation and operation information. In some cases, if the system is uniquely configured, a drawing showing system interconnects is supplied.



Never connect or disconnect any electrical component or connecting cable while power is applied, or serious damage may result.

2.5.1. DC Servo Motor Wiring

When stages are equipped with standard Aerotech DC motor and encoder combinations, refer to the appropriate motor manuals and documentation for additional installation and operation information.

Chapter 3: Operating Specifications

The surrounding environment and operating conditions can affect the performance and service life of the stage. This chapter provides information on ideal environmental and operating conditions. Also included are instructions for estimating load and torque required to turn the ballscrew given various loadings.

3.1. Environmental Specifications

The environmental specifications for the ATS150 are listed in the following table.

Table 3-1: Environmental Specifications

Ambient Temperature	Operating: 10° to 35° C (50° to 95° F) The optimal operating temperature is 20° C ±2° C (68° F ±4° F). If at any time the operating temperature deviates from 20° C degradation in performance could occur. Contact Aerotech for information regarding your specific application and environment. Storage: 0° to 40° C (32° to 104° F) in original shipping packaging
Humidity	Operating: 40 percent to 60 percent RH The optimal operating humidity is 50 percent RH.
	Storage: 30 percent to 60 percent RH, non-condensing in original packaging
Altitude	Operating: 0 to 2,000 m (0 to 6,562 ft) above sea level Contact Aerotech if your specific application involves use above 2,000 m or below sea level.
Vibration	Use the system in a low vibration environment. Excessive floor or acoustical vibration can affect stage and system performance. Contact Aerotech for information regarding your specific application.
Dust Expo- sure	The ATS150 stages have limited protection against dust, but not water. This equates to an ingress protection rating of IP50.
Use	Indoor use only



Do not expose the stage to environments or conditions outside the specified range of operating environments. Operation in conditions other than those specified can cause damage to the equipment.

3.2. Accuracy and Temperature Effects

The ATS150 series stages are designed to have maximum accuracy at 68° F.

The accuracy of the stages ball-screw is a key element in the overall positioning accuracy. An offset error can be expected if the temperature of the ball-screw differs from 68° F. As the temperature of the ball-screw increases, the actual position from the motor will be greater by a factor of

$$\frac{7\times 10^{\text{-6} \text{ inches}}}{(\text{inches of travel})\times (\text{deg F})} \quad \text{ or } \quad \frac{11.3\times 10^{\text{-6}}\,\text{mm}}{(\text{mm of travel})\times (\text{deg C})}.$$

Similarly, as the temperature of the ball-screw decreases, the actual positioning will be less by the same factor. The value specified in the "inches of travel" and "mm of travel" represent the distance from the center of the stage to the bearing on the motor end of the stage.

NOTE: Ball-screw temperature is dependent on the speed of the stage and duty cycle. Higher speeds and duty cycles produce greater ball-screw heating.

3.3. Basic Specifications

The ATS 150 series positioning stage and motor specifications are provided in Table 3-2 and Table 3-3.

Table 3-2: ATS150 Series Positioning Stage Specifications

Basic Model			ATS150-100	ATS150-150	ATS150-200	ATS150-250	
Total Travel			100 mm (4 in)	150 mm (6 in)	200 mm (8 in)	250 mm (10 in)	
Drive System			Super Precis	Super Precision Ground Ball Screw/Brushless Servomotor (BMS60-A-D25-E1000H)			
Bus Voltage				Up to 1	60 VDC		
Continuous Curre	nt	Apk		Up to	2.3 A		
Continuous Currei	iii.	Arms		Up to	1.6 A		
Feedback			No	ncontact Rotary	Encoder (1000 li	ne)	
	2 mm/rev lea	d	0.5 µm (2	20 μin) @ 4000 s	teps/rev Motor R	esolution	
Resolution	4 mm/rev lea	d	1.0 µm (4	40 μin) @ 4000 s	teps/rev Motor R	esolution	
recorduon	LN Linear Er	ncoder	•	μm (0.04 μin - μin)	N/A	N/A	
Maximum Travel	2 mm/rev lea	d		115 mm/s	s (4.5 in/s)		
Speed ⁽¹⁾	4 mm/rev lea	d		230 mm/s	s (9.0 in/s)		
	Horizontal			45.0 kg	(99.2 lb)		
Maximum Load ⁽²⁾	Vertical			25.0 kg (55.1 lb)			
Loau	Side		25.0 kg (55.1 lb)				
	HALAR ⁽³⁾		±1.0 μm (±40 μin)				
Accuracy	Ball Screw	Standard	+2,-4 μm (+80,-160 μin)	+2,-5 µm (+80,-200 µin)	+2,-8 μm (+80,-320 μin)	+2,-10 μm (+80,-400 μin)	
	LN	HALAR ⁽³⁾	±1.0 µm		N/A	N/A	
		Standard	· · · · · · · · · · · · · · · · · · ·	±200 μin)	N/A	N/A	
		HALAR ⁽³⁾			ι (±20 μin)		
Repeatability	Ball Screw	Standard	±1.0 µm (±40 µin)				
(Bidirectional)	LN		±0.5 μm (±20 μin) N/A N/A			N/A	
	D:# # 1	HALSF		1 μm/25 mm (40 μin/in)			
	Differential	Standard		2 µm/25 mr	n (80 µin/in)		
Straightness and Flatness	Maximum Deviation	HALSF	±1.0µm (±40 µin)	±1.5 μm (±60 μin)	±2.0 μm (±80 μin)	±3.0 µm (±120 µin)	
		Standard	±2.0 μm (±80 μin)	±3.0 μm (±120 μin)	±4.0 μm (±160 μin)	±5.0 μm (±200 μin)	
Pitch and Yaw		8 arc sec	10 arc sec	12 arc sec	14 arc sec		
Nominal Stage	Less Motor		6.1 kg (13.4 lb)	7.5 kg (16.5 lb)	7.9 kg (17.4 lb)	8.4 kg (18.5 lb)	
Weight	With Motor		7.2 kg (15.9 lb)	8.6 kg (19.0 lb)	9.0 kg (19.8 lb)	9.5 kg (20.9 lb)	
Construction			Aluminum Body/Stage and Table; Clear Anodize Finish				
(1) Excessive duty eve	le may impact acc	uracv					

⁽¹⁾ Excessive duty cycle may impact accuracy.

 $^{(2) \} Payload\ specifications\ are\ for\ single\ axis\ system\ and\ based\ on\ ball\ screw\ and\ bearing\ life\ of\ 2500\ km\ (100\ million\ inches)\ of\ travel.$

⁽³⁾ Available with Aerotech controllers.

⁽⁴⁾ Specifications are for single-axis systems, measured 50 mm above the tabletop. Performance of multi-axis systems is payload and workpoint dependent. Consult factory for multi-axis or non-standard applications.

Table 3-3: Motor Specifications

Model	BMS60	
Winding Designation	-A	
Performance Specifications (1,5)		
Stall Torque, Continuous (2)	N-m	0.33
	oz-in	46.2
Peak Torque (3)	N-m	1.31
	oz-in	184.9
Rated Speed	rpm	4,000
Rated Power Output, Continuous	watts	112.0
Electrical Specifications (5)		
BEMF Constant (line to line, max)	Volts pk / krpm	19.0
Continuous Current, Stall (2)	Amp pk	2.3
	Amp rms	1.6
Peak Current, Stall (3)	Amp pk	9.2
	Amp rms	6.5
Torque Constant (4,8)	N-m / Amp pk	0.14
	oz-in / Amp pk	20.1
	N-m / Amp rms	0.20
	oz-in / Amp rms	28.4
Motor Constant (2,4)	N-m / √W	0.050
	oz-in / √W	7.02
Resistance, 25 °C (line to line)	ohms	8.4
Inductance (line to line)	mH	1.30
Maximum Bus Voltage	VDC	340
Thermal Resistance	°C/W	1.73
Number of Poles	Р	8

⁽¹⁾ Performance is dependent upon heat sink configuration, system cooling conditions, and ambient temperature

⁽²⁾ Values shown @ $75\,^{\circ}$ C rise above a $25\,^{\circ}$ C ambient temperature, with housed motor mounted to a $250\,\text{mm}\,\text{x}\,250\,\text{mm}\,\text{x}\,6\,\text{mm}$ aluminum heat sink

⁽³⁾ Peak torque assumes correct rms current, consult Aerotech

⁽⁴⁾ Torque Constant and Motor Constant specified at stall

⁽⁵⁾ All performance and electrical specifications +/- 10 percent

⁽⁶⁾ Maximum winding temperature is 100 $^{\circ}\text{C}$, Thermistor trips at 100 $^{\circ}\text{C}$


⁽⁷⁾ Ambient operating temperature range: 0 °C - 25 °C, consult Aerotech for performance in elevated ambient temperatures

⁽⁸⁾ All Aerotech amplifiers are rated Apk; use torque constant in N-m/Apk when sizing

3.4. Life Expectancy and Load Capability

The accuracy specification of ATS150 series stages is measured at the center of travel (with no load), located 1.75 inches above the table, with the stage in a horizontal position.

It is recommended the load be symmetrically distributed (the payload should be centered on the stage table and the entire stage should be centered on the support structure). For cantilever loading, refer to Figure 3-1 for a graph of the maximum allowable load versus the distance of the load's center of gravity to the center of the stage table.



Cantilevered Load Capability of the ATS150 Series

Loading vs. Travel Life of the ATS150 Series

Figure 3-1: Load Capability and Travel Life of the ATS150 Stages

Load capacity and life expectancy are inversely related (that is, as loading increases, life expectancy will decrease). The ball-screw is usually the critical component when determining life expectancy.

To determine the life expectancy in a given application, refer to the loading vs. travel life graph in Figure 3-1. Be sure to consider dynamic loading when using the ATS150 series stage for high-speed applications. Life expectancy is calculated using the following steps.

1. Determine the loading percentage of the stage. Use the following equation:

$$Loading\ Percentage = \frac{Applied\ Load}{Max.\ Load\ Specification} \times 100\%$$

2. Multiply the result by the proper factor from the Applied Load Coefficient Table (Table 3-4).

3. Refer to the loading vs. travel life graph in Figure 3-1.

Table 3-4: Applied Load Coeffcients

Operating Conditions	Factor
Smooth operation (no shocks)	1.0
Normal operating conditions	1.5

In applications using a cantilevered load, the life expectancy is calculated as follows:

1. Determine the equivalent, direct-acting loading force of the applied load. Use the following equation:

2. Use the cantilever load chart (see Figure 3-1) to determine the maximum direct loading force using the following equation.

3. Calculate the loading percentage using the calculated loading forces.

$$Loading \ Percentage = \frac{Loading \ Force}{Max \ Loading \ Force} \times 100\%$$

- 4. Multiply the result by the proper factor from the Applied Load Coefficient Table (Table 3-4).
- 5. Refer to the loading vs. travel life graph in Figure 3-1.

The following conversions can be used during load calculations.

1 kg = 2.2 pounds

2.54 cm = 1 in

1 kg-cm = 13.9 oz-in

16 oz-in-sec2 = 1 lb-in-sec2

1 revolution approximately equals 6.28 radians.

The approximate amount of torque required to turn the ball-screw of an ATS150 series stage can be found from Figure 3-2.

$$Torque_{REQ} = \frac{(Axial Load) \times (Lead of Screw)}{2 \times \pi \times (Efficiency)}.$$

For ATS150 series stages, the efficiency is rated at 90 percent (0.90).



Maximum load is 100 pounds.




Figure 3-2: Torque Required to Turn ATS150 Series Ball-screw with Various Loads and Leads

3.5. Optical Limit Switch Assembly

ATS150 series stages are equipped with optical limit switch assemblies (#690B1371), which are used to indicate maximum travel condition.

3.5.1. Limit Switch Operation

Limit switches are mounted perpendicularly to table travel at each end of the stage, and have an emitting light source and detector. When the carriage interrupts the light path from the emitter to the detector, a clockwise (CW) or counter-clockwise (CCW) limit signal (active low) will indicate an over travel condition.




Figure 3-3: ATS150 Internal View Showing Optical Limit Switch Assembly



If the stage is driven approximately 1.5 mm beyond the electrical limit, it will encounter the mechanical stop. Although the operating speed of the stage might be relatively slow, damage to the stage could result.

Unless specifically modified, the CW limit is activated when the stage table is at the end of travel opposite the motor end.

3.5.2. Limit Interface

A six-pin printed circuit board connector is provided to facilitate wiring of the limit interface. The mating connector is AMP part number 640234-6.

Table 3-5:	Limit I	nterface	Pin A	Assignments
------------	---------	----------	-------	-------------

Pin#	Function	Notes
J1-1	+5V input	+5V at 25mA (source 1mA and sink 2.6 mA) or
		+12V at 25mA (source 3mA and sink 19mA [DJ0])
		(For +12V @ 25mA, remove wire jumper 1-2)
J1-2	Reserved	
J1-3	Signal common	
J1-4	Reserved	
J1-5	CCW limit-n	Active low (4049 CMOS output)
J1-6	CW Limit-n	Active low




Figure 3-4: ATS150 Series Limit Switch Wiring

The CCW Limit-N output equals a logical 1 when the limit is not active. Typically, this is a value of 2.4 V at 0.8 mA. The CCW limit-N output equals a logical 0 when the limit is active. Typically, this is a value of 0.4 V at 12.8 mA. The CW Limit-N output behaves similarly.

NOTE: The terms clockwise (CW) and counter-clockwise (CCW) refer to the rotation direction of the motor while looking into the shaft of the motor. For ATS150 series stages, a clockwise (CW) rotation of the motor causes the stage table to move away from the motor. Conversely, a counter-clockwise (CCW) rotation of the motor causes the stage table to move toward the motor. The exception is if an optional "foldback" motor is used, in which case the directions are reversed.

3.6. Vacuum Operation

As an option, Aerotech will prepare the ATS150 series stage for operation in a vacuum environment. As part of this preparation, meticulous attention to detail during modification, cleaning and assembly results in a stage with optimal performance in high vacuum applications (10⁻⁶ torr). This preparation includes:

- Lubrication with vacuum-compatible lubricants (see Section 4.4. for lubricants)
- Exclusive use of materials with excellent vacuum outgas performance
- Elimination of situations that may allow gases to become temporarily trapped during pump down.
- Extensive cleaning and bake-out prior to special assembly in a clean environment and packing in a nitrogen-filled bag.

3.6.1. Special Guidelines

To ensure that the stage will continue to perform well in the vacuum environment, follow the guidelines listed below (in addition to standard handling, installation and lubrication guidelines outlined earlier in this manual).

- 1. Do not remove the stage from the sealed bag until it is ready for use. Use Teflon gloves in a clean environment to prevent any contaminants from adhering to the surface of the stage.
- During the installation process use cleaned, vented stainless steel fasteners when securing the stage. A motor cover and cable connector might be supplied with the stage motor. These should be removed before the stage is used in vacuum applications.
- In a vacuum environment, the lack of convective heat transfer could result in excessive motor operating temperatures. This, coupled with the viscous nature of vacuum-compatible greases, might make it necessary to de-rate performance specifications.

To reduce the amount of heat generated, Aerotech offers special controllers that reduce the current supplied to the motor when it is in an idle state. Contact Aerotech for assistance.

Chapter 4: Maintenance

This chapter will cover information about intervals between lubrications, detail the lubrication and inspection process, and cover which lubricants are recommended for use.

NOTE: The bearing area must be kept free of foreign matter and moisture; otherwise, the performance and life expectancy of the stage will be reduced. Always operate the stage with the hard cover and side seals in place to help keep dirt out.



To minimize the possibility of bodily injury, confirm that all electrical power is disconnected prior to making any mechanical adjustments.

4.1. Lubrication Schedule

Lubricant inspection and replenishment in ATS150 series stages depends on conditions such as duty cycle, speed, and the environment. An inspection interval of once per month is recommended until a trend develops for the application. Longer or shorter intervals may be required to maintain the film of lubricant on the bearing surfaces.

In general, ball-screws and linear bearings require lubricant after 20 million inches of travel.

The ball-screw end bearings and motor bearings are shielded, and should not need to be re-lubricated under normal use.

4.2. Lubrication and Cleaning Process

The lubrication and cleaning process is outlined in the steps that follow. Before beginning lubrication, please see Section 4.4. for recommended lubricants.

- 1. Drive the stage table to one end of travel and remove power to the stage.
- 2. Remove the socket head screws on the edges of the stage table and pull the bellows way-covers back toward the edge of the stage to reveal the inside of the stage.
- 3. Remove any accumulated dust or debris from the inside of the assembly.
- 4. Remove any dirty or dried lubricant from the lead-screw/ball-screw. Use a clean cloth with a side-to-side motion to clean the thread roots. Manually turn the ball-screw to clean its entire circumference. A cotton swab soaked in solvent may be used to remove stubborn debris.
- 5. Clean the end of the ball-screw nut and wiper with a clean cloth or cotton swab. These areas can be accessed from the underside of the stage.
- 6. Clean the linear bearing guides using a similar technique.
- 7. After the solvent has evaporated (if solvent is used), apply a thin, continuous film of lubricant to the lead-screw/ball-screw threads and linear bearing guides. A good quality, natural bristle artist's brush makes an excellent applicator.
- 8. Refasten the bellows way-covers and screws to the stage table.
- 9. Restore power to the stage, drive the stage table to the opposite end of travel, and remove power.
- 10. Repeat steps 2 through 7.



To minimize the possibility of bodily injury, confirm that all electrical power is disconnected prior to making any mechanical adjustments.

4.3. Important Notes on Lubrication

When cleaning and lubricating components of the ATS150 series stages:

- 1. Be sure to use a clean, dry, soft, and lint–free cloth for cleaning.
- 2. Take the opportunity during the lubrication procedure to inspect the linear motion guides for any damage or signs of wear.
- 3. In applications that have multiple stages bolted together to form multiaxis systems, the orthogonality can be altered upon loosening the stage tables of the support stages. In this case, lubricant should be applied with a hypodermic needle through the aperture hole in the base of the stage (or the optional aperture in the stage table). Otherwise, a master square must be used to realign the XY or YZ orthogonality.
- 4. Further disassembly of the stage is not recommended because proper assembly and calibration can only be done at the factory.

4.4. Recommended Lubricants and Cleaning Solvents

For standard environments, use Dow Corning BR2 on the ball-screw and the linear bearings. For vacuum environments use Castrol Braycote 602 EF on the ballscrew and linear bearings.

Appendix A: Warranty and Field Service

Aerotech, Inc. warrants its products to be free from defects caused by faulty materials or poor workmanship for a minimum period of one year from date of shipment from Aerotech. Aerotech's liability is limited to replacing, repairing or issuing credit, at its option, for any products that are returned by the original purchaser during the warranty period. Aerotech makes no warranty that its products are fit for the use or purpose to which they may be put by the buyer, where or not such use or purpose has been disclosed to Aerotech in specifications or drawings previously or subsequently provided, or whether or not Aerotech's products are specifically designed and/or manufactured for buyer's use or purpose. Aerotech's liability or any claim for loss or damage arising out of the sale, resale or use of any of its products shall in no event exceed the selling price of the unit.

Aerotech, Inc. warrants its laser products to the original purchaser for a minimum period of one year from date of shipment. This warranty covers defects in workmanship and material and is voided for all laser power supplies, plasma tubes and laser systems subject to electrical or physical abuse, tampering (such as opening the housing or removal of the serial tag) or improper operation as determined by Aerotech. This warranty is also voided for failure to comply with Aerotech's return procedures.

Laser Products

Claims for shipment damage (evident or concealed) must be filed with the carrier by the buyer. Aerotech must be notified within (30) days of shipment of incorrect materials. No product may be returned, whether in warranty or out of warranty, without first obtaining approval from Aerotech. No credit will be given nor repairs made for products returned without such approval. Any returned product(s) must be accompanied by a return authorization number. The return authorization number may be obtained by calling an Aerotech service center. Products must be returned, prepaid, to an Aerotech service center (no C.O.D. or Collect Freight accepted). The status of any product returned later than (30) days after the issuance of a return authorization number will be subject to review.

Return Procedure

After Aerotech's examination, warranty or out-of-warranty status will be determined. If upon Aerotech's examination a warranted defect exists, then the product(s) will be repaired at no charge and shipped, prepaid, back to the buyer. If the buyer desires an airfreight return, the product(s) will be shipped collect. Warranty repairs do not extend the original warranty period.

Returned Product Warranty Determination

After Aerotech's examination, the buyer shall be notified of the repair cost. At such time, the buyer must issue a valid purchase order to cover the cost of the repair and Non-warranty Deterfreight, or authorize the product(s) to be shipped back as is, at the buyer's expense. Failure to obtain a purchase order number or approval within (30) days of notification will result in the product(s) being returned as is, at the buyer's expense. Repair work is warranted for (90) days from date of shipment. Replacement components are warranted for one year from date of shipment.

Returned Product mination

At times, the buyer may desire to expedite a repair. Regardless of warranty or outof-warranty status, the buyer must issue a valid purchase order to cover the added rush service cost. Rush service is subject to Aerotech's approval.

Rush Service

On-site Warranty If an Aerotech product cannot be made functional by telephone assistance or by Repair sending and having the customer install replacement parts, and cannot be returned to the Aerotech service center for repair, and if Aerotech determines the problem could be warranty-related, then the following policy applies:

> Aerotech will provide an on-site field service representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs. For warranty field repairs, the customer will not be charged for the cost of labor and material. If service is rendered at times other than normal work periods, then special service rates apply.

> If during the on-site repair it is determined the problem is not warranty related, then the terms and conditions stated in the following "On-Site Non-Warranty Repair" section apply.

On-site Non-warranty If any Aerotech product cannot be made functional by telephone assistance or pur-**Repair** chased replacement parts, and cannot be returned to the Aerotech service center for repair, then the following field service policy applies:

> Aerotech will provide an on-site field service representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs and the prevailing labor cost, including travel time, necessary to complete the repair.

Company Address Aerotech, Inc.

101 Zeta Drive Pittsburgh, PA

15238-2897

Phone: (412) 963-7470

Fax: (412) 963-7459

Appendix B: Technical Changes

Table B-1: Current Changes (1.01.00)

Section(s) Affected	General Information
All	Complete revision of style and formatting. Some sections were moved or combined with other sections. No technical information was altered as part of this change.
Section 1.2.	Updated model numbers
Section 1.4.	Added section
Section 3.1.	Added section
Chapter 2: Installation, Section 2.1., Section 2.3. , Section 2.5., and Section 1.3.	Added safety information and warnings
Section 0.1.	Revised specifications, added motor specifications
Section 3.5.1.	Changed warning to specify distance in millimeters
Section 4.4.	Changed recommended lubricants

Table B-2: Archived Changes

Revision	Section(s) Affected	General Information
1.00.00		New manual

Index

	N
Α	Non-Coplanar10
Accuracy14	•
Attaching the Payload11	Ontired Limit Cruitab Assembly
.	Optical Limit Switch Assembly
B A5	P
Basic Specifications	Preparing the Mounting Surface10
С	s
cable12	safety procedures. 6
Coplanar10	Securing the Stage to the Mounting Surface11
D	Standard Features. 2
DC Servo Motor Wiring	_
Declaration of Incorporation. 8	Т
Dodard and Formorporation.	Temperature Effects14
E	Travel Distance
Electrical Installation	Travel Life. 2
Environmental Specifications	U
L	Unpacking and Handling the Stage
Life Expectancy	
Limit Interface21	V
Limit Switch Assembly20	Vacuum Operation
Limit Switch Operation	w
Load Capability17	Warnings 6
Lubricants	
Recommended	
Lubrication and Cleaning24	
Lubrication Schedule	
M	
Model Numbers. 9	
model numbers. 9	
multiaxis combinations	

Reader's Comments

ATS150 Series Stage Manual P/N: EDA125, March 21, 2011

Revision 1.01.00

Please answer the questions below and add any suggestions for improving this document.



Is the manual:	Yes	No
Adequate to the subject		
Well organized		
Clearly presented		
Well illustrated		

How do you use this document in your job? Does it meet your needs? What improvements, if any, would you like to see? Please be specific or cite examples.

	Stage/Product Details	Name	
Model#		Title	

	Stage/Product Details	Name	
Model #		Title	
Serial #		Company Name	
Date Shipped		Address	
Customer Order #			
Aerotech Subsidiary Order #		Email	

Mail your comments to:	Fax to:
Aerotech, Inc.	412-967-6870
101 Zeta Drive Pittsburgh, PA 15238 U.S.A.	Email:
	service@aerotech.com